

Instruction for iPolar Replacement (CEM40/GEM45/CEM60/CEM70/CEM120)

Ver 1.2, 11/9/2020

1. Remove the iPolar cap. For CEM40 and GEM45, loosen and remove the two locking screws, for CEM60/70/120, loosen the two setting screws.



GEM45



CEM40/60/70/120

4. Put a new iPolar into the adapter and tighten the two setting screws.



S

2. Pull out the iPolar and disconnect the cable.



CEM40/GEM45



CEM60/70/120

5. Connect the wire to the iPolar



3. Loosen the two setting screws and take the iPolar apart from its adapter.



6. Put back the iPolar and tighten the locking screws for GEM45. Or tighten the setting screws on CEM40/60/70/120.



GEM45



CEM40/60/70/120